



SNOWBLOWER

OPERATOR AND PARTS MANUAL

For Residential and Industrial Snowblowers

MANUFACTURED BY:
SMYTH WELDING & MACHINE SHOP LTD.
37452 GLEN'S HILL RD.
R.R. #2
AUBURN, ONTARIO
N0M 1E0
TEL: (519) 529-7212
FAX: (519) 529-3277
www.smythwelding.com
Email: info@smythwelding.com

Introduction

Thank you for choosing a **Smyth Welding** snowblower. This well built blower is designed for residential and industrial snow removal needs. There are hydraulic and PTO models with a variety of additional options that will suit all your requirements. We are confident this equipment will meet your expectations in terms of quality, performance and reliability.

Please read this manual completely before operating your snowblower and keep it for future reference. It contains important information and was made to assist you in the safe operation of your new snowblower and to ensure it performs to its fullest capabilities.

Before using this snowblower, any person who will be operating the sweeper must be familiar with the safety recommendations and the operating instructions. Please read carefully and be sure to understand and follow all recommendations and procedures.

If you require additional information on your snowblower, please contact your **Smyth Welding** snowblower dealer.

Information needed for warranty and ordering parts:

Date of purchase: _____

Serial Number: _____

Model Number: _____

Special Options: _____

Warranty Information

Smyth Welding & Machine Shop Ltd. products are warranted for a period of 1 year from the date of original purchase, by the original purchaser, to be free from defects in material and workmanship under correct and normal use and proper applications.

Smyth Welding & Machine Shop Ltd. obligations under this warranty shall be limited to the repair or exchange at **Smyth Welding's** option, of any **Smyth Welding** product or part which proves to be defective as provided. The customer will return his unit to his dealer where it was purchased and if the dealer agrees with the warranty, they must then notify **Smyth Welding** to get authorization.

The equipment must be installed, operated and maintained in accordance with **Smyth Welding's** instructions.

This warranty does not extend to goods damaged or subject to accident, abuse or misuse after shipment from **Smyth Welding**, nor to goods altered or repaired by anyone other than an authorized **Smyth Welding** representative.

Smyth Welding shall in no event be responsible for any consequential damages of any nature whether special or general, direct or indirect.

Any warranty or claim which differs from that set out is unauthorized by **Smyth Welding & Machine Shop Ltd.** and is the warranty only of the party making it. **Smyth Welding & Machine Shop Ltd.** makes no other warranty, expressed or implied and the original user's sole remedy for breach thereof is as set forth.

To obtain warranty a copy of original bill of sale is required and all claims must be submitted within a 30 days from date of equipment failure.

Important Note:

The snowblower gearbox shafts are made with a special alloy steel. Moreover, they are case hardened to increase capacity to shock load. These shafts cannot be broken under normal loads. However, undesirable objects may enter the snowblower and either bend or break the gearbox shaft. It is understood that the gearbox cannot be built to resist every possible overload, and consequently, gearbox shafts will not be replaced under warranty

WARNING: Unfortunately, the snowblower will be faced with forgotten or hidden objects under the snow, such as, chain, tires, stones, pieces of wood, etc...in spite of our snowblower's strength and durability, they are not built to handle all of these conditions.

Safety Information

This operator's manual should be regarded as part of the snowblower. Suppliers of both new and secondhand snowblowers are advised to keep documentation indicating that this manual was provided with the snowblower.

Obey all safety instructions listed in this section and throughout this manual. Failure to do so could result in serious injury or death.

- Know all your controls and know how to quickly stop all power unit movement and the snowblower movement.
- Know and follow good work practices when assembling, mounting, maintaining, repairing, removing and storing this product.
- All shields and guards are to be in place before operation of snowblower.
- Wear appropriate personal protection equipment.
- Do not wear loose clothing, loose or uncovered hair, or any accessories that can catch in moving parts.
- Never allow anyone, except the operator, to be around the power unit on this product when it is in use.
- Do not start up unless others are clear of the work area.
- Do not allow riders on this product or the power unit.
- Do not stand or climb on this unit when operating.
- Do not place any part on your body under any part of this product unless the product is turned off and securely resting on adequate blocking or on the ground.
- Never leave equipment unattended with the power unit running or with this product raised.
- Ensure all safety warning decals are legible. Contact Smyth Welding & Machine Shop Ltd. for replacement of missing or damaged safety decals.



Operation Information

Never operate the snowblower in poor visibility or without proper lighting.

It is dangerous to use a tractor which is too big or too powerful, it may overload the snowblower. If the tractor is too high, extreme angles at PTO shaft universal joints will result and the life of these U-joints will be shortened dramatically.

Place the snowblower on a firm, level surface that is large enough to accommodate this product, your power unit and all works involved in the mounting process.

Adjust skid shoes for proper ground clearance of the cutting edge.

Clear the auger and drum area of any ice before starting the snowblower.

Check hose clearances for any interference.

Inspect all areas where the blower will be used and remove any object that could cause damage to the unit.

Never discharge chute towards people or animals. Adjust chute properly when near buildings, windows and vehicles.

Operate the controls from the operator's station only.

Never leave equipment unattended with the engine running or with this product raised.

Be aware of added weight and width of this product. Reduce travel speeds accordingly, especially when traveling on rough ground.

Use care on slopes and excessive incline areas. Reduce speed in slippery conditions.

Keep this product close to the ground and under control at all times.

Check all hardware holding the snowblower to the power unit making sure all is tight.

Replace any damaged or fatigued hardware with properly rated fasteners.

Make sure all hydraulic hardware and hydraulic fittings are tight.


PTO Safety:

- Do not perform any adjustments, cleaning, maintenance or repairs with the engine running. The engine must be stopped and the PTO disengaged.
- Put the PTO control in the neutral position before starting the engine
- If undue vibrations are felt, disengage the PTO, stop the engine and look for causes of vibration. Vibration is usually the indicator of a problem.
- At the end of operation, disengage the PTO, lower the snowblower, put the transmission in neutral, apply the parking brake, stop the engine and remove the key from the ignition

Hydraulic Safety:

- Hydraulic fluid under pressure can penetrate the skin and cause serious injury or death.
- Hydraulic leaks under pressure may not be visible, wear safety glasses, protective clothing, and use a sound piece of cardboard when searching for hydraulic leaks. **DO NOT USE YOUR HANDS.**
- Before connecting or disconnecting hydraulic hoses, read your power unit's operator's manual for detailed instructions on connecting and disconnecting hydraulic attachments.
- Make certain that all parts meet the specifications for this product when installing or replacing hydraulic hoses or fittings.
- Refer to your power unit's operator's manual and this manual for procedures and intervals, then inspect and maintain the entire hydraulic system to insure that the fluid remains clean, that all devices function properly, and that there is no fluid leaks

Manual Rotator Assembly



Place the crank assembly into the tube receiver on top of the fan housing and tighten the set bolt.


Standing on the hitch side of the snowblower, facing the auger, turn the hood opening to the 9'o'clock position.

Take one end of the cable and slide it through the cable clamp welded at the base of the hood opening, and into the cable clamp welded at the upper end of the crank assembly, then tighten both clamps.

Turn the crank in a clockwise rotation until the opening of the hood reaches the 3'o'clock position.

Put the remaining length of the cable through the cable clamp located at the lower end of the crank assembly and tighten.

Hydraulic Rotator Assembly



With the hydraulic hood turner assembly firmly bolted in place, route the cable around the hood and attach each end of the cable to the corners of the "D" ring as shown.

With the hood opening pointing directly over the auger, position the tubing in the "D" ring so it points at the center of the hood base, then tighten all clamps.

Side Discharge

Orbital motor powered to allow for either left or right side discharge, increasing fan capacity and reducing the required horse power.



Rotate fan housing either left or right completely until it hits the stops to use the side discharge.

Align the arrows to use the chute.

Maintenance

Stop the unit and disengage all power before doing any adjustments or service to your snowblower. See your Smyth Welding dealer to replace any worn or damaged parts.

Chain:

Carefully check the teeth on the sprocket, if they are worn to a hooked shape, the sprockets should be replaced to assure full capacity performance and a satisfactory life from the new chain. Tight chain causes an additional load which increases wear on chain joints, sprockets and shaft bearings.

Slack chain produces vibration, which may result in excessive chain wear, noise or shock loading.

Tighten chain allowing ¼" sag in the bottom span as the chain wears.

Sprocket:

Inspect sprockets for problems which lead to replacement.

- Wear on the sides, which is due to misalignment
- Tooth wear (indicated by hooking)
- Broken teeth
- Cracks that might lead to failure
- Wobbling of sprockets on shaft

Bearings:

- grease after every 8 hours of use

Shear Bolts:

- replace with grade 2 or 5 for PTO series 20-40-50-60-80

Make sure this bolt is very tight in order to keep the efficiency of the shearing mechanism.


Gearbox:

- use 80W90 gear oil

PTO:

Point A -grease after every 16 hours of use

Point B –grease after every 8 hours of use



Telescopic tubes of PTO should overlap a minimum length to meet ideal conditions for power transmission.

The following table could be used as a guide to find the maximum permissible length of PTO:

PTO size	Over-all length		Overlap
	Closed	Maximum	
T20	29¾"	41"	5"
T40	30½"	40½"	6"
T50	36½"	50"	7"
T60	37¾"	47¼"	7"
T80	36"	47¼"	7"


PTO shafts are made to transmit power with angles at universal joints; however, these angles should be kept to a minimum.

H.P.
60 @ 540 RPM

P.T.O. angles
5°
10°
15°
20°
25°

Estimated life in hours
450 hours
195 hours
90 hours
40 hours
20 hours

How to determine P.T.O. angle




- 1) Lower blower on ground.
- 2) Take measures A, B & L
- 3) Subtract B of A ($A - B = C$)
- 4) Divide L by C ($L \div C = F$)
- 5) Compare F Factor in table below to find P.T.O. angle (interpolate, if necessary).


A = P.T.O. height at tractor
B = P.T.O. height at blower
C = A - B
L = Cross center distance in working position

F FACTOR	ANGLE
6	10°
3.75	15°
2.75	20°
2.15	25°
1.75	30°

Previous examples clearly demonstrate that universal joint angle is directly related with life of P.T.O.. In order to reduce angle, it is necessary to increase the distance between snowblower and tractor.




TOO LARGE ANGLES AT P.T.O. JOINTS TO AVOID




REASONABLE ANGLES AT P.T.O. JOINTS ACCEPTABLE

If it is impossible to increase the distance between snowblower and tractor, in order to maintain a reasonable angle at P.T.O., it is recommended to use a larger size of P.T.O., that is a greater capacity P.T.O. (please refer to your dealer for more details).

For snowblowers of 100 H.P., an additional gearbox is also available that can be mounted on existing snowblower gearbox, which increases the input shaft height, reducing angle at P.T.O. joints. This gearbox also has an input speed of 1000 R.P.M., which greatly increases P.T.O. capacity.



NON-EQUAL ANGLES AT P.T.O. JOINTS TO AVOID



EQUAL ANGLES AT P.T.O. JOINTS RECOMMENDED

Angles at each end of P.T.O.

A popular habit is to change snowblower angle in order to obtain a better scraping effect. This practice can become harmful to the P.T.O., angle at each end being unequal. There will be a fan speed variation as well as a drastic increase of load on cross and bearings. **To avoid**, it is recommended to keep tractor P.T.O. shaft and snowblower input shaft always parallel.

Replacement Parts

	102-HS 108-HS 120-HD	102-HD 108-HD	96-S 96-D	84-S 84-D 90-PT	66-S 72-S 78-PT	48-S 54-S 60-LS	Side Discharge
Gear Box	T279A	T27D	T27D	T27D	T281A	L25A	
PTO	T80	T60	T60	T50	T40	T20	
Spline Coupler (sleeve)	1 3/4" 20 spline	1 1/4" 19 spline	1 1/4" 19 spline	1 1/4" 19 spline	1 1/4" 19 spline	1" 15 spline	
Shear Coupler (sprocket)	80SB12 1 3/4"	60SB12H 1 1/4"	60SB12H 1 1/4"	60SB12H 1 1/4"	60SB12 1 1/4"	50SB12H-1" 50A12x1"	
Chain	83" of 80 101" of 80 97 1/2" of 80H 108" of 80H Side discharge 111" of 80H	71" of 60H 84" of 60H	71" of 60 84" of 60D	71" of 60 84" of 60D	61" of 60	48" of 50	#60 H
Idler Sprocket	S18011HX 3/4"	S16015x 5/8"	S16015x 5/8"	S16015x 5/8"	S160B15x 5/8"	S150B17x 5/8"	(2) S160B15x 5/8"
Sprocket	80A38x1 3/8" or x1 1/4" 80A45x1 1/2" 80A45 x 2" Oil Bath 8032 w/hub 8045 w/hub	60A38x1 3/8"	60A38x1 3/8"	60A38x1 3/8"	60A38x1 3/8"	50A36x1"	6012
Bearing & Flange	Cross shaft UC209 x 1 3/4" Auger UC207 x 1 3/8" 207 flangettes	Cross shaft UC207 x 1 1/4" Auger UC207 x 1 3/8" 207 flangettes	Cross shaft UC207 x 1 1/4" Auger UC207 x 1 3/8" 207 flangettes	Cross shaft UC207 x 1 1/4" Auger UC207 x 1 3/8" 207 flangettes	Cross shaft UC207 x 1 1/4" Auger UC207 x 1 3/8" 207 flangettes	Cross Shaft & Auger UC 205 x 1" 205 flangettes	
Oil Seal	50x72x8 52x85x10 45x72x8	35x72x10 40x80x12	35x72x10 40x80x12	35x72x10 40x80x12	35x52x7	25x47x7	
PTO tube	Outer 4mmx54mm Inner 4mmx63mm	Outer 4mmx45mm Inner 3mmx51.6mm	Outer 4mmx45mm Inner 3mmx51.6mm	Outer 4mmx45mm Inner 3mmx51.6mm	Outer 4.5mmx36mm Inner 3.4mmx43.5mm	Outer 4mmx29mm Inner 3.2mmx36mm	
Shear pins Grade 2 or 5	PTO 12mmx65mm Auger 5/16" x 1 1/2"	PTO 10mmx55mm 3/8" x 2" Auger 5/16" x 1 1/2"	PTO 10mmx55mm 3/8" x 2" Auger 5/16" x 1 1/2"	PTO 10mmx55mm 3/8" x 2" Auger 5/16" x 1 1/2"	PTO 8mmx50mm Auger 1/4" x 1 1/2"	PTO 6mmx40mm Auger 1/4" x 1"	

Chain Box Maintenance

The purpose of the chain box is to increase the PTO capacity from 540 rpm to 1000 rpm and to reduce angles at both ends of the PTO in working position by increasing the input shaft height.

T27D Chain box

After first 25 working hours, drain the oil out of the chain box and fill it in with 2.6 L of SAE 80W90 oil. Drain and change oil every season.

RH25000 Gear box

First oil change should be after 50 working hours, then after each 1000 hours. Use 1.6L of SAE 80w90 or a comparable synthetic oil. Drain and change the oil every working season.

PTO shear bolt

When the PTO is running at 1000 rpm instead of 540 rpm, the shear bolt value must be changed. On a PTO size 80, for 540 rpm the shear bolt is 12mm, grade 5. For 1000 RPM It has to be changed to a shear bolt 7/16" dia. Grade 2.

Adjusting the chain tension

After 10 working hours, the chain's adjustment must be checked. In order to do so, verify the backlash between the input and the output shaft by turning the input shaft in both directions while the output shaft remains still. If there is a play of .010 to .015, the chain must then be readjusted as follows:

- Remove PTO from the chain box.
- Unscrew the bolts from covers around the input shaft on both sides of the chain box
- With a hammer and screw-driver or a chisel, gently turn both covers in the same direction until the nest hole of the cover is in line with the threaded hole of the chain box.


By turning input shaft cover, center to center, the distance of shafts will be changed adjusting the chains tension.

Make sure that the covers are turned in the same direction and by the same number of holes, otherwise, both shafts will not be parallel and serious damages might arise.

Verify the backlash between both shafts, if the difference is too high, repeat the operation. If the backlash is correct, reinstall the bolts and the PTO.


Verify the backlash every 100 working hours.

Chain Box Assembly for T27D (7', 8' & 7 1/2' Pull-type)




- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Casing with plug 2. Bearing 6212 3. Seal Cover (47x7) 4. Sprocket 80-3A26 5. Chain 80-3x36" L 6. Bearing 6309 7. Input cover with hole 8. Sprocket 80-3A14 9. Input shaft 1 3/8"x6 spline(010.036) 10. Oil Seal (45x65x8) TC double lip 11. Bolt 5/16"-18 UNCx4 1/2" 12. Nut 5/16"-18UNC 13. Square Key 1/2"x2 1/2" | <ol style="list-style-type: none"> 14. Spacer (2-2 3/8"-0.568) 15. Input cover w/o hole 16. O-ring as-248 (National) 17. Square key 3/8"x2 1/2" 18. Output shaft 1 3/8"x6 spline(010.039) 19. Oil Seal (60x80x10)TC double lip 20. Casing w/o plug 21. Slotted spring pin 3/16"x3/4" 22. Bolt 5/16"-18 UNC x3/4" 23. Air vent 1/2"-14 NPT 24. Sight glass 3/4"-14 NPT 25. Drain plug 1/2"-14 NPT |
|--|--|

Gear Box Assembly for RH 25000 (8 1/2', 9' & 10')




- | | |
|--|---|
| <ol style="list-style-type: none"> 1 Lower Housing 2 Upper Housing 3 Hollow Cover 4 Seal 55x90x81 5 Guard 6 Mid Gear Shaft 7 Shim 8 Seal 65x90x8 9 Grease Fitting 10 End Cap 11 Bearing 12 Spacer 13 Round End Key 14 Output Gear 15 Name Plate | <ol style="list-style-type: none"> 16 Output Shaft 17 Seal Retainer 18 Button Head Screw 19 Washer 20 End Cap 21 Bearing 22 Input Gear Shaft 23 Magnetic Plug 24 Plug 3/4" 25 Plug 1/2" 26 Dowel Pin 27 Pressure Vent 28 Bolt 29 Nut 30 Bolt |
|--|---|

SMYTH 48" ,54" & 60" LS SNOWBLOWER




- | | |
|-----------------------|--|
| 1. Fan | 13. Bolts |
| 2. Hood w/ gf | 14. $\frac{5}{8}$ "x 3 $\frac{1}{2}$ " bolt |
| 3. Hood Turner | 15. $\frac{5}{8}$ " Flat Washers |
| 4. Hitch Pin | 16. 5017 Idler Sprocket |
| 5. Gearbox | 17. $\frac{5}{8}$ " Machinery Bushing, Nut and Lock Washer |
| 6. Spline Coupler | 18. Bolts |
| 7. Cross Shaft | 19. Flangette |
| 8. Shear Coupler w/gf | 20. Bearing |
| 9. Spacer | 21. Flangette |
| 10. Flangette | 22. Sprocket |
| 11. Bearing | 23. Auger |
| 12. Flangette | |

SMYTH 66", 72" & 78" SNOWBLOWER




- | | | | |
|-----|--|-----|--|
| 1. | Hitch Pin | 12. | Idler Sprocket |
| 2. | Gearbox | 13. | $\frac{5}{8}$ " Flat Washers |
| 3. | Spline Coupler | 14. | $\frac{5}{8}$ "X3 $\frac{1}{2}$ " Bolt |
| 4. | Cross Shaft | 15. | $\frac{1}{2}$ "X 1 $\frac{1}{2}$ " Bolts |
| 5. | Shear Coupler w/gf | 16. | Bearing w/gf |
| 6. | Spacer | 17. | $\frac{1}{2}$ "X1 $\frac{1}{2}$ " Bolt |
| 7. | Flangette | 18. | Sprocket |
| 8. | Bearing | 19. | Auger |
| 9. | Flangette w/gf | 21. | Fan |
| 10. | Carriage Bolts $\frac{3}{8}$ "X1" | 22. | Hood w/gf Located at Base |
| 11. | $\frac{5}{8}$ " Machinery Bushing, Nut And Lock Washer | 23. | Hood Turner- Crank |

SMYTH 84", 96", 102", 108" & 120" SNOWBLOWER





- | | |
|-------------------|---|
| 1. Fan | 11. $\frac{3}{8}$ " x 1" Carriage Bolt |
| 2. Auger Bearing | 12. $\frac{5}{8}$ " x $3\frac{1}{2}$ " Idler Bolt |
| 3. Hitch Pin | 13. Spacer washer |
| 4. Gearbox | 14. Idler Sprocket |
| 5. Spline Coupler | 15. $\frac{1}{2}$ " x $1\frac{1}{2}$ " Bearing Bolt |
| 6. Cross Shaft | 16. Auger Bearing |
| 7. Shear Coupler | 17. Auger Sprocket |
| 8. Shear Pin | 18. Auger |
| 9. Flangettes | |
| 10. Bearing | |

Hydraulic Snowblower Parts




- 13. Fan
- 14. Sprocket
- 15. Auger
- 16. Auger Bearing
- 17. Grader Bolt
- 18. Cutting Edge
- 19. Roller Chain


Valve Block



Orbital Hood Turner




L-25A Gearbox (for 48", 54" & 60LS)




1.	0.124.6005.00 Crown	Wheel Z24 M3.25
2.	8.5.1.00004	Snap Ring 25 Uni7435
3.	8.4.1.00015	Parallel Key A 8x7x25
4.	0.100.7507.00	Shim 25.6x0.7
5.	8.0.1.00598	Bearing 6205
6.	8.7.3.00257	Oil Seal 25x47x7
7.	0.124.7103.00	Bearing
8.	0.100.7506.00	Shim 25.6x0.6
9.	0.124.2429.00	Shaft 1"
10.	0.124.2429.00	Plug 3/8" gas
11.	1.124.0302.00	Casing A
12.	1.124.303.00	Casing A
13.	8.1.2.00248	Bolt M8x45 8,8
14.	8.2.1.00382	Hex Nut M8
15.	0.124.6258.00	Pinion Shaft Z16 M3.25
16.	8.7.6.00191	O-Ring OR-3062

T20 PTO (for 48", 54" & 60LS)




- | | | | |
|-----------------|-------------------------------|--------------------|---------------------------------------|
| 1. 166.026.004 | Push pin set 1 3/8" | 17. 121.022.526.10 | U joint for outer tube |
| 2. 141.022.010 | Hub B02 | 18. 121.022.570.10 | U joint for inner tube |
| 3. 190.000.024 | Ball 7/32" | 19. 123.220.647.10 | Half female shaft |
| 4. 151.012.005 | Yoke for B02 | 20. 123.220.343.10 | Half male shaft |
| 5. 180.012.130 | Cross journal set | 21. 180.012.007 | Guard retaining collar for outer tube |
| 6. 151.012.003 | Outer yoke | 22. 180.012.013 | Cone for outer tube |
| 7. 190.000.012 | Roll pin for outer tube | 23. 190.000.215 | "DANGER" Label for outer shield tube |
| 8. 190.000.216 | "DANGER" Label for outer tube | 24. 156.111.143 | Outer shield |
| 9. 152.120.289 | Outer tube | 25. 157.111.241 | Inner shield |
| 10. 153.120.181 | Inner tube | 26. 190.000.019 | Bolt |
| 11. 190.000.011 | Roll pin for inner tube | 27. 180.012.012 | Cone for inner tube |
| 12. 151.012.002 | Inner yoke | 28. 180.012.006 | Guard retaining collar for inner tube |
| 13. 151.012.304 | Special yoke | 29. 142.221.134 | Half female shield |
| 14. 190.000.020 | Grease nipple M8x1 | 30. 142.221.231 | Half male shield |
| 15. 165.000.509 | Bolt M6x40 cl.8.8 & nut | 31. 180.016.025 | Safety chains |
| 16. 143.220.001 | Complete shear bolt B02 | 32. 142.220.252 | Complete shield type P |

T-281A Gearbox (for 66",72" & 78")




1.	1.281.0300.00	Casing
2.	0.281.2207.00	Shaft 1 ¼"
3.	0.259.7500.00	Shim 48.0
4.	8.0.1.00025	Bearing 6207
5.	8.4.1.00057	Parallel Key A 10x8x30
6.	0.281.6200.00	Pinion shaft Z13 M5
7.	8.7.3.00028	Oil Seal 35x52x7
8.	0.259.6000.00	Crown wheel Z19 M5
9.	0.259.7505.00	Shim 35.3x0.5
10.	8.5.1.00005	Snap ring 35 Uni7435
11.	0.259.7506.00	Shim 35.3x0.6
12.	8.7.6.00191	O-Ring OR-3062
13.	0.281.7100.00	Plug
14.	8.1.2.01174	Bolt M8x55 8,8
15.	8.2.1.00382	Hex nut M8 8

T40 PTO (for 66", 72" & 78")




- | | |
|---|---|
| 1. 166.026.009 Push pin set 1 3/8" old type | 18. 121.024.609.10 U joint for outer tube |
| 2. 141.024.271 Push pin yoke 112 old type | 19. 121.024.610.10 U joint for inner tube |
| 3. 180.014.130 Cross journal set | 20. 123.240.673.10 Half female shaft with shielding |
| 4. 151.014.006 Outer yoke | 21. 123.240.386.10 Half male shaft with shielding |
| 5. 190.000.014 Roll pin for outer tube | 22. 180.013.012 Guard retaining collar for outer tube |
| 6. 190.000.216 "DANGER" label for outer tube | 23. 180.013.016 Cone for outer tube |
| 7. 152.140.280 Outer tube | 24. 190.000.019 Bolt |
| 8. 153.140.188 Inner tube | 25. 190.000.215 "DANGER" label for outer shield tube |
| 9. 190.000.012 Roll pin for inner tube | 26. 156.141.554 Outer shield |
| 10. 151.014.007 Inner yoke | 27. 157.141.279 Inner shield |
| 11. 151.014.012 Yoke for B02 | 28. 180.013.015 Cone for inner tube |
| 12. 190.000.020 Grease nipple M8x1 | 29. 180.013.011 Guard retaining collar for inner tube |
| 13. 190.000.022 Ball 1/4" | 30. 142.241.153 Half female shield |
| 14. 141.024.270 Hub B02 with interfering clamp bolt | 31. 142.241.253 Half male shield |
| 15. 165.000.505 Bolt M8x50 cl.8.8 & nut | 32. 180.016.025 Safety chains |
| 16. 165.000.525 Bolt M12x1, 25x70 cl.8.8 & nut | 33. 142.240.293 Complete shield type P |
| 17. 143.240.008 Complete shear bolt B02 | |

T-27D Gearbox (for 84", 90PT & 96")




- | | |
|-------------------------------------|--------------------------------------|
| 1. 0.267.0301.00 Casing | 13. 8.5.1.00005 Snap ring 35 Uni7435 |
| 2. 8.0.9.00024 Bearing 30208 | 14. 8.0.1.00025 Bearing 6207 |
| 3. 8.5.2.00030 Snap ring 80 | 15. 8.5.2.00131 Snap ring 72 Uni7437 |
| 4. 8.7.1.00748 Double lip seal | 16. 0.244.7500.00 Shim 51.5 |
| 5. 0.110.7500.00 Shim 79,7 | 17. 0.267.4218.00 Shaft |
| 6. 0.267.5000.00 Gear Z18 M6.15 | 18. 0.132.5002.00 Gear Z18 M6.15 |
| 7. 8.5.1.00029 Snap ring 40 Uni7435 | 19. 8.6.5.00006 Plug 3/8" gas |
| 8. 8.0.9.00026 Bearing 30207 | 20. 8.1.1.01031 Bolt M10x14 |
| 9. 0.267.7100.00 Spacer | 21. 0.267.1300.00 Cover |
| 10. 0.259.7500.00 Shim 48.0 | 251. 8.6.7.00161 Oil filler plug |
| 11. 8.7.1.00152 Double lip seal | 500. 0.124.7101.00 Plate |
| 12. 0.267.2000.00 Shaft 16/32" Z19 | |

T50 PTO (for 84" & 90PT)




- | | |
|--|--|
| 1.166.026.009 Push pin set 1 3/8" old type | 18.121.025.582.10 U joint for outer tube |
| 2.141.025.230 Push pin yoke 112 old type | 19.121.025.583.10 U joint for inner tube |
| 3.180.015.130 Cross journal set | 20.123.250.674.10 Half female shaft with shielding |
| 4.151.015.011 Outer yoke | 21.123.250.359.10 Half male shaft with shielding |
| 5.190.000.015 Roll pin for outer tube | 22.180.015.009 Guard retaining collar for outer tube |
| 6.190.000.216 "DANGER" Label for outer tube | 23.180.016.023 Cone for outer tube |
| 7.152.150.209 Outer tube | 24.190.000.019 Bolt |
| 8.153.150.109 Inner tube | 25.190.000.215 "DANGER" label for outer shield tube |
| 9.190.000.014 Roll pin for inner tube | 26.156.151.109 Outer shield |
| 10.151.015.012 Inner yoke | 27.157.151.209 Inner shield |
| 11.151.015.024 Yoke for B02 | 28.180.016.022 Cone for inner tube |
| 12.190.000.020 Grease nipple M8x1 | 29.180.015.008 Guard retaining collar for inner tube |
| 13.190.000.022 Ball 1/4" | 30.142.251.151 Half female shield |
| 14.141.025.260 Hub B02 with interfering clamp bolt | 31.142.251.248 Half male shield |
| 15.165.000.511 Bolt M10x55 cl.8.8 & nut | 32.180.016.025 Safety chains |
| 16.165.000.525 Bolt M12x1,25x70 cl.8.8 & nut | 33.142.250.285 complete shield type P |
| 17.143.250.016 Complete shear bolt B02 | |

T60 PTO (for 96")




- | | |
|---|--|
| 1. Complete collar yoke 1-3/8 Z6 | 38. Safety chains |
| 2. Cross journal set 30.2x92 | 40. Complete shield-short or long |
| 5. Outer Yoke | 51. Collar set |
| 11. Roll pin for outer tube | 71. Yoke B02 |
| 12. Bushing w/ gf | 72. Ball 5/16" |
| 14. Complete outer tube 27" | 73. Bolt & nut |
| 15. Inner tube 27" | 74. Hub |
| 16. Roll pin for inner tube | 75. Bolt & nut |
| 21. Inner yoke | 76. Grease fitting |
| 30. Complete shear bolt B02 | 90. U joint for outer tube |
| 31. Guard retaining ring | 91. U joint for inner tube |
| 32. Cone for outer tube | 94. Half female shield |
| 33. Bolt | 95. Half male shield |
| 34. Outer shield | 96. Half female shaft w/ shielding |
| 35. Inner shield | 97. Half male shaft w/ shielding |
| 36. Cone for inner tube | 98. "DANGER" label for outer tube |
| 37. Guard retaining collar for inner tube | 99. "DANGER" label for out shield tube |

T-279A Gearbox (for 102", 108" & 120")




1.	0.279.0300.00	Casing T4
2.	8.5.1.00533	Snap ring 50 Uni7435
3.	8.1.1.00501	Bolt M10x22 8,8
4.	0.712.7500.00	Shim 70.3
5.	8.4.1.00978	Parallel key B 14x9x40
6.	0.279.3010.00	Shaft
7.	8.7.1.01097	Oil seal 50x72x8
8.	8.0.9.00469	Bearing 30210
9.	0.279.1300.00	Cover
10.	0.279.6000.00	Gear Z21 M7,14
11.	0.248.7200.00	Gasket
12.	0.279.5000.00	Gear Z21 M7,14
13.	8.0.9.00125	Bearing 32209
14.	0.279.2000.00	Shaft 1 3/4" Z20
15.	0.279.1301.00	Extension AC
16.	8.0.9.00143	Bearing 30209
17.	8.7.3.01096	Oil seal 52x85x10
18.	0.252.7500.00	Shim 65.3
19.	8.3.8.00065	Spring washer x1, 25C40B0N
20.	8.2.5.00064	Locknut M40x1,5 H9
21.	0.252.7525.00	Shim 45.3x2.5
22.	8.7.1.00981	Double lip seal 45x72x8
23.	8.6.6.0021	Plug 3/8" Gas
24.	0.244.7510.00	Shim 40.3x1.0
500	0.124.7101.00	Plate

T80 PTO (for 102", 108" & 120")



- | | |
|---|---|
| 1. 166.026.009 Push pin set 1 3/8" old type | 19. 143.280.016 Complete shear bolt B05 |
| 2. 141.028.161 Push pin yoke 112 old type | 20. 121.028.637.10 U joint for outer tube |
| 3. 180.018.130 Cross journal set | 21. 121.028.636.10 U joint for inner tube |
| 4. 151.018.133 Outer yoke | 22. 123.280.680.10 Half female shaft with shielding |
| 5. 190.000.243 Roll pin for outer tube | 23. 123.280.371.10 Half male shaft with shielding |
| 6. 190.000.216 "DANGER" Label for outer tube | 24. 180.019.121 Guard retaining collar for outer tube |
| 7. 180.019.114 Shield support | 25. 180.019.123 Cone for outer tube |
| 8. 152.198.117 Outer tube | 26. 190.000.019 Bolt |
| 9. 159.190.025 Hardened inner tube | 27. 190.000.215 "DANGER" Label for outer shield tube |
| 10. 190.000.271 Roll pin for inner tube | 28. 156.198.117 Outer shield |
| 11. 151.018.134 Inner yoke | 29. 157.198.117 Inner shield |
| 12. 151.018.023 Yoke for B05 | 30. 180.019.124 Cone for inner tube |
| 13. 190.000.021 Grease nipple M10x1 | 31. 180.019.122 Guard retaining collar for inner tube |
| 14. 190.000.023 Ball 5/16" | 32. 142.281.146 Half female shield |
| 15. 141.028.162 Hub B05 with interfering clamp bolt | 33. 142.281.255 Half male shield |
| 16. 166.000.542 Grease nipple kit | 34. 180.016.025 Safety chains |
| 17. 165.000.539 Bolt M12x65 cl.10.9 & nut | 35. 142.286.016 Complete shield type P |
| 18. 165.000.584 Bolt M12x1,25x90 cl.8.8 & nut | |

T27D Gearbox for Front Mount Blowers




S.d.M. 01.0613

Ratio		Rated input r.p.m.	Rated input power HP kW		Rated output torque da Nm	Weight Kg	Oil <input checked="" type="checkbox"/> Grease <input type="checkbox"/>	Lubricant Quantity lt.				
1 : 1.12		540	55	40.4	69.4	22	SAE.140EP	1.1				
Gear Arrangement 	Bevel couplings				Cylindrical couplings				Bearings			
	Helical <input type="checkbox"/>	Teeth number			Module	Helical <input type="checkbox"/>	Teeth number			Module	A 6012	
Straight <input checked="" type="checkbox"/>	Z 1	Z 2	Z 3	Z 4	M	Helical <input type="checkbox"/>	Z 1	Z 2	Z 3	Z 4	M	D 5012
	17	19			6.25							G 30207
Components material												
Casing	Shaft X	Shaft Z		Bevel gear		Spur gear						
G 25 UNI ISO 185	20 CrNi4	20 MnCr5		20 CrNi4								
F												
G												
H												

COMER INDUSTRIES reserves the right to make any change to this product without prior public acknowledgement
 COMER INDUSTRIES Sp.A. 42046 Villanova di Reggio (RE) Italia Tel. 0522\974111 (9 Lines) Telefax 0522\973249

T27D Gearbox for Front Mount Blowers



- | | |
|-------------------------------|---------------------|
| 1. Double lip seal | 12. Bearing 30207 |
| 2. Snap ring | 13. Snap ring |
| 3. Shim | 14. Bearing 6207 |
| 4. Bearing 6012 | 15. Snap ring |
| 5. Bolt M10x20 | 16. Shaft |
| 6. Nut, hex M8 | 17. Double lip seal |
| 7. Sleeve (hollow crown gear) | 18. Spacer |
| 8. Plug 3/8" gas, solid | 19. Casing |
| 9. Snap ring | 20. Bolt M8x14 |
| 10. Cover | 21. Pinion |
| 11. Shim | 22. Plug 3/8" gas |

Trouble Shooting

<u>Quick Disconnect Yoke</u>		
Pin tight or seized	-quick-disconnect pin dirty (insufficient maintenance)	-clean, oil and follow service instructions
Pin damaged/broken	-quick-disconnect pin defective(forced engagement, incorrect handling)	-replace quick-disconnect pin
Pin damaged in locking portion	-excessive shaft length -axial loads too high	-shorten shaft length(cut both telescopic tubes as well as shields and remove burrs) -replace disconnect pin & -clean and grease telescopic tubes, and replace both tubes, if necessary
<u>Yoke</u>		
Distorted or worn	-excessive shaft length -axial loads too high -excessive working angle and torque	-shorten shaft length (cut both telescopic tubes as well as shields and remove burrs) -replace disconnect pin & -clean and grease telescopic tubes, and replace both tubes, if necessary -change PTO length -determine proper PTO angle (see page 12)

<u>Cross Kit</u>		
Cross arms broken	-extreme torque	-engage PTO carefully
Bearing caps turning in cross journal	-excessive torque or angle	-change PTO length -determine proper PTO angle
Overheating or Accelerate wear	-inadequate grease	-grease parts at proper intervals
<u>Telescopic Tube</u>		
Failure or twisting	-extreme torque -tube is too short	-engage PTO carefully -replace tube with correct length
Accelerated wear	-tube is too short -inadequate grease	-replace tube with correct length -grease parts at proper intervals
<u>PTO Shield</u>		
Excessive bearing wear	-inadequate grease	-grease parts at proper intervals
Safety chain failure	-incorrect safety chain mounting	-change safety chain mounting angularity
Damaged or worn	-contact with implement	-adjust to eliminate interference
<u>Hydraulic System</u>		
Over heating	-oil level low -restriction in hoses -poppet is unseated	-add oil until it reaches 2" from top -remove bends in hoses and any other obstruction -reseat poppet or replace coupler
Quick coupler leaks	-tank is over filled	-drain oil until it reaches 2" from top
Oil flows from breather cap on tank	-exceeding maximum gpm and psi	-contact your dealer
Motor seals leak	-motor is failing	-contact your dealer



www.smythwelding.com